


## ACVLV0 – Wall Mount

## Component Parts/Packing List

### Valve Module, B-Style, 8 Zone, Large Terminal, Premium Surge

Installation in Wall Mount Enclosure




Ref.	Part No.	Description	Qty
	<b>ACVLV0</b>	<b>Valve Module, B-Style, 8-Zone, Large Terminal, Premium Surge</b>	<b>1</b>
1	ACVLV0	Valve Module, B-Series, 8 Zone, Large Terminal, Premium Surge	1
2	ARCBL1.5	Cable, Valve Module Bus, 1.5 in (38.1 mm)	1
3	ARCBL4	Cable, Valve Module Bus, 4.0 in (101.6 mm)	1
4		Screws and Washers	4

## ACLVL0 – Wall Mount

## Final Installation

### Valve Module, B-Style, 8 Zone, Large Terminal, Premium Surge

#### Installation in Wall Mount Enclosure




Front View

#### Final Installation of Valve Module(s):

Remove Wall Mount Enclosure Keypad display and two front extension panels & screws; set screws aside to re-attach panels after Valve Module installation.

1. Install Valve Module (1) in first available position. Use four small screws & washers (4).
2. Use proper cable to connect Valve Module. Longer cable (3) is used for Valve Module in the first position only to connect to ACPAC, thereafter, the shorter cable (2) is used between valve modules.
3. Re-attach Wall Mount Keypad and extension panels with screws. (See Keypad & Panel Install below.)



Keypad & Panel Re-install